

# 按钮触发模式（指令触发模式）

1、



开始设置

2、



按钮模式 (默认)

3、



结束设置

## 串口参数:

1、



开始设置

2、



115200

3、



结束设置

# 解码时间:

1、



开始设置

2、



解码时间 (毫秒)

3、



3

4、



0

5、



0

6、



0

7、



0

8、



结束设置

# 设置触发指令为 16 54 0D:

- 1、用串口软件发指令（16 进制），而不是通过扫码：07 57 A1 19 16 54 0D FE 71（图一）
- 2、用串口软件发指令（16 进制），而不是通过扫码：05 57 A0 08 01 FE FB（图 2）




图 1




图 2